

PIG Trough Style Roof Leak Diverter

Drain Assembly Instructions

1. Identify clear drain fitting located in the middle of the unit. The fitting is shipped in the inverted position, with threads on the interior. **(fig. A)**
2. Insert your finger into the centre of the drain fitting and pull through, so the threads are on the outside. **(fig. B)**
3. Locate included hose fitting and attach a 3/4" drainage hose (not included). We recommend using TLS690, our reinforced clear drainage hose. **(fig. C)**
4. Insert the male end of the hose assembly (hose connector and drainage hose) into the female end of the drain fitting. Secure it by tightening the ring. **(fig. D)**

NOTE: Depending on your application, it may be easier to perform Step 4 after hanging your Leak Diverter.

Hanging Instructions

1. Identify the structure from which you'll hang the Leak Diverter.
2. Insert PVC rods into pockets along each side of the diverter. **(fig. E)**
3. Feed hanging straps (not included) through grommets, one at a time, as you hang each corner.
4. Hang the diverter as level as possible to create the proper drainage. **(fig. F)**
5. Attach hose assembly (if not already done above) and position hose into a drain or container.

